

TALENT

Serie 500



TL57-



actiu.com/talent500-assembly





actiu.com/warranty



two people



1

TL570/TL572/TL573/TL574



2

TL570/TL572/TL573/TL574



TALENT

Serie 500



TL57-



actiu.com/talent500-assembly




actiu.com/warranty






two people

3 TL572/TL573/TL574



ATENCIÓN: El cable del mando debe pasar sobre el larguero.
CAUTION: The control cable must run over the beams.
ATTENTION : Le câble de commande doit être acheminé au-dessus de la barre transversale.

4 TL572/TL573/TL574



5 TL572/TL573/TL574

